


IMPORTANT NOTE: For installation with included thread-on nut covers, a minimum of 6 threads or half inch of threads extending through the top of each lug nut is required. If exposed threads do not meet the minimum requirement, please purchase metal washers (UP Item 10262-1) to secure the base onto the wheel, will require removal of the lug nut to use the metal washers/rings.



United Pacific

No.	DESCRIPTION	Qty/Kit
A	OFF-ROAD STYLE COVER	1
B	THREAD-ON NUT COVER	10
C	MOUNTING BASE	1
D	PLASTIC WHEEL PROTECTOR FILM	1

Fits standard 22.5" X 8.25" steel wheels and aluminum wheels.



Installation Instruction:

1. For installation on an aluminum wheel, insert the enclosed plastic wheel protector film (D) between the aluminum wheel and the mounting base (C).
2. Align all 10 holes of the mounting base (C) over the studs and wheel nuts.
3. Use lug nut socket tool to install the 33 mm thread-on nut covers (B) on each stud by turning clockwise until tight. Mounting base (C) should now be secure on each nut.
4. Center the top cover (A) inside flange to the top of the wheel base (C).
5. Firmly tap the cover onto the base with palm of hand. May require several tries due to the tight tolerance on the two parts.
6. A "pop" sound should be heard once Aero cover is snapped on the mounting base.

CAUTION: THE PLASTIC RIM PROTECTOR MUST BE USED WHEN THIS PRODUCT IS PLACED ON ANY ALUMINUM RIM TO PREVENT COSMETIC DAMAGE ON THE SOFT ALUMINUM RIM. UNITED PACIFIC SHALL NOT BE RESPONSIBLE FOR IMPROPER INSTALLATION OF THE PRODUCT.

Item No. 10343
 Product Name: Off-Road Style Front Axle Cover Kit With 33mm Thread-On Nut Covers-Chrome

Rev No. 06122023