

Door Window Shade Freightliner Cascadia

Installation instructions

09/02/2020

1. Remove the mirror from passenger side.
2. Attach the supplied bracket to the truck as shown. Do not tighten fully. Leave a gap of about 1/8" between the bracket and the truck body.
3. Slide the window shade into the gap between the bracket and truck body. Hold the shade up against the door and align properly. Mark the truck with pencil as a guide for installation.
4. Remove shade and prepare the mounting surface of the door according to instructions provided.
5. Remove the backing of tape from the shade and attach it to the door using pencil marks as a guide, while also ensuring the shade is tucked in between the bracket and truck body (applying pressure for sufficient period of time will help adhesion of two sided tape)
6. Fully tighten the supplied bracket to the truck.
7. Attach the mirror to the supplied bracket as shown.
8. Repeat for driver side, fastening only with 3M tape as the driver side has no mirror.

