

# Wiring Instructions

For Item Numbers: 33010, 33012



No.	DESCRIPTION	FUNCTION
A	Red Wire	High (Right Hand)
B	Black Wire	Low
C	White Wire	Ground (-)
D	Yellow Wire	High (Left Hand)

