

# MINIBAR



**RED:** To +VDC (ECE R65 version - fuse @8A)  
(SAE version - fuse @6A)  
(ECONO version - fuse @3A)

**BLACK:** To Chassis Ground (-)

**BLUE:** Flash patterns & Synchronization

- Momentarily apply +VDC to **BLUE** for Flash Pattern change
- Continuously apply +VDC to **BLUE** for Low Power
- Connect **BLUE** wires of all minibars together for synchronization; all units must be set at the same pattern

**NOTE:** ECONO version contains only 1 flash pattern.

**WARNING:** Do not look directly into LEDs while in operation; may cause momentary blindness and/or eye damage.

Model: with Dual button cigar-plug.



### WARNING:

It is not recommended to use magnetically mounted warning devices on outside of vehicle in motion. Usage is at the sole risk and responsibility of the user. (For moving vehicles, please use Power Mags)

## FLASH PATTERNS


Momentarily apply +VDC to **BLUE** or push Flash Pattern button:

- Once for next pattern
- Quick 3 times for reset to FP#1


FP#	Flash Patterns	FP#	Flash Patterns	FP#	Flash Patterns
1	Random	9	Single H/L (split)	17	Single H/L
2	Single (split)	10	Single	18	Steady (half)
3	Double (split)	11	Double	19	Steady
4	Quad (split)	12	Quad	20	Single [2Hz]
5	Quint (split)	13	Quint	21	Double [2Hz R65]
6	Mega (split)	14	Mega	22	Triple [2Hz]
7	Ultra (split)	15	Ultra	23	Quad [2Hz]
8	Single-Quad (split)	16	Single-Quad		

- Note:**
- This unit may not factory set at FP#1
  - Actual approval based on model ordered.


## 1-BOLT MOUNT



## 2-BOLT MOUNT



## 4-BOLT MOUNT



## MAGNETIC MOUNT

